

Roof Paint Procedure



Tel: 081 098 9631

Email: info@coatmasters.co.za

Web: www.coatmasters.co.za

Surface Preparation

Unpainted or weathered cement roof tiles:

- Clean thoroughly with a high-pressure water jet or by scrubbing with a hard-bristle or wire brush and water.
- Ensure the roof is completely dry before proceeding.
- If the tiles are still powdery or friable after cleaning, apply a *Bonding Liquid* (e.g., Plascon CVI 14). Allow to dry for at least 16 hours before painting.

Previously painted roof tiles:

- Inspect and remove all flaking or loose paint using a scraper or wire brush.
- Clean entire surface with *Sugar Soap* solution (e.g., 500g in 5L water).
- Rinse with clean water and allow to dry.
- If areas are bare or show signs of friability, treat with *Bonding Liquid* (e.g., CVI 14) and allow to dry before painting.

Application

- Stir *Roof Paint* (e.g., Plascon Nuroof Cool) thoroughly before use.
- Apply by brush, roller, or airless spray.
- Apply 2 full coats, allowing at least 2 hours drying time between coats.
- Do not dilute the paint.

Additional Notes

- Avoid painting when the temperature is below 10°C or in wet weather conditions.
- Start at the apex of the roof and work down, completing one sheet or tile section at a time to avoid lap marks.
- Ensure good ventilation and safety measures while working on roofs.

Disclaimer

The procedures recommended in this document are intended as general guidelines and are provided in good faith based on CoatMasters' experience. They do not constitute a guarantee, as methods may vary depending on specific site conditions. Clients are encouraged to consult with us for any clarifications regarding the suitability of a specific procedure for their project.